

EASTERN[®] PUSHER

FORK BUSHING ASSEMBLY



1. Unpack frame fork and all parts by removing all protective packaging.



2. Notice the quick release and two bearing spacers on the fork tube.



3. Ensure that both nylon bearings are inserted fully into the frame. If they are not completely inserted tap them lightly until the shoulders are flush with frame.



4. With one bearing spacer on the bottom of the fork tube insert the fork into the frame.



5. Once the fork is completely inserted into the frame place the top bearing spacer on the fork tube.



6. Place quick release on the fork tube making sure the quick release tightens towards the front of the bicycle.



7. Insert handle bars into fork.



8. Adjust to the desired height making sure the split in the fork and the adjustment area on the quick release are aligned.



9. Tighten quick release and test to make sure wheel and handle bars do not slip. Due to the bushing headset, a little play in the headset/forks is to be expected.



MORE INFO & FULL SPECS AT

WWW.EASTERNBIKES.COM